CAMPBELL SCIENTIFIC
WHEN MEASUREMENTS MATTER

# USER MANUAL

# *CS475, CS476 and CS477*
# *Radar Water Level Sensor*

*Issued: 10.9.13*

Copyright © 1998-2013 Campbell Scientific, Inc.
Printed under licence by Campbell Scientific Ltd.

CSL 855

# Guarantee

This equipment is guaranteed against defects in materials and workmanship. This guarantee applies for twelve months from date of delivery. We will repair or replace products which prove to be defective during the guarantee period provided they are returned to us prepaid. The guarantee will not apply to:

- Equipment which has been modified or altered in any way without the written permission of Campbell Scientific
- Batteries
- Any product which has been subjected to misuse, neglect, acts of God or damage in transit.

Campbell Scientific will return guaranteed equipment by surface carrier prepaid. Campbell Scientific will not reimburse the claimant for costs incurred in removing and/or reinstalling equipment. This guarantee and the Company's obligation thereunder is in lieu of all other guarantees, expressed or implied, including those of suitability and fitness for a particular purpose. Campbell Scientific is not liable for consequential damage.

Please inform us before returning equipment and obtain a Repair Reference Number whether the repair is under guarantee or not. Please state the faults as clearly as possible, and if the product is out of the guarantee period it should be accompanied by a purchase order. Quotations for repairs can be given on request. It is the policy of Campbell Scientific to protect the health of its employees and provide a safe working environment, in support of this policy a "Declaration of Hazardous Material and Decontamination" form will be issued for completion.

When returning equipment, the Repair Reference Number must be clearly marked on the outside of the package. Complete the "Declaration of Hazardous Material and Decontamination" form and ensure a completed copy is returned with your goods. Please note your Repair may not be processed if you do not include a copy of this form and Campbell Scientific Ltd reserves the right to return goods at the customers' expense.

Note that goods sent air freight are subject to Customs clearance fees which Campbell Scientific will charge to customers. In many cases, these charges are greater than the cost of the repair.

Campbell Scientific Ltd,
Campbell Park, 80 Hathern Road,
Shepshed, Loughborough, LE12 9GX, UK
Tel: +44 (0) 1509 601141
Fax: +44 (0) 1509 601091
*Email: support@campbellsci.co.uk*
*www.campbellsci.co.uk*

# *PLEASE READ FIRST*

## About this manual

Please note that this manual was originally produced by Campbell Scientific Inc. primarily for the North American market. Some spellings, weights and measures may reflect this origin.

Some useful conversion factors:

**Area:** 1 $in^2$ (square inch) = 645 $mm^2$

**Length:** 1 in. (inch) = 25.4 mm
1 ft (foot) = 304.8 mm
1 yard = 0.914 m
1 mile = 1.609 km

**Mass:** 1 oz. (ounce) = 28.35 g
1 lb (pound weight) = 0.454 kg

**Pressure:** 1 psi ($lb/in^2$) = 68.95 mb

**Volume:** 1 UK pint = 568.3 ml
1 UK gallon = 4.546 litres
1 US gallon = 3.785 litres

In addition, while most of the information in the manual is correct for all countries, certain information is specific to the North American market and so may not be applicable to European users.

Differences include the U.S standard external power supply details where some information (for example the AC transformer input voltage) will not be applicable for British/European use. *Please note, however, that when a power supply adapter is ordered it will be suitable for use in your country.*

Reference to some radio transmitters, digital cell phones and aerials may also not be applicable according to your locality.

Some brackets, shields and enclosure options, including wiring, are not sold as standard items in the European market; in some cases alternatives are offered. Details of the alternatives will be covered in separate manuals.

Part numbers prefixed with a "#" symbol are special order parts for use with non-EU variants or for special installations. Please quote the full part number with the # when ordering.

## Recycling information

At the end of this product's life it should not be put in commercial or domestic refuse but sent for recycling. Any batteries contained within the product or used during the products life should be removed from the product and also be sent to an appropriate recycling facility.

Campbell Scientific Ltd can advise on the recycling of the equipment and in some cases arrange collection and the correct disposal of it, although charges may apply for some items or territories.

For further advice or support, please contact Campbell Scientific Ltd, or your local agent.

CAMPBELL SCIENTIFIC
WHEN MEASUREMENTS MATTER

Campbell Scientific Ltd, Campbell Park, 80 Hathern Road, Shepshed, Loughborough, LE12 9GX, UK
Tel: +44 (0) 1509 601141 Fax: +44 (0) 1509 601091
*Email: support@campbellsci.co.uk*
*www.campbellsci.co.uk*

# Contents

*PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.*


**1. Introduction ..... 1**

**2. Cautionary Statements ..... 1**

**3. Initial Inspection ..... 2**

**4. Quickstart ..... 2**

4.1 Step 1 — Mount and Align the Sensor ..... 2
4.2 Step 2 — Do a False Echo Learn Command ..... 4
4.3 Step 3 — Do a Set Water Stage Command ..... 5
4.4 Step 4 — Use SCWin Short Cut to Program Datalogger and Generate Wiring Diagram ..... 6

**5. Overview ..... 8**

5.1 Components and Hardware ..... 9

**6. Specifications ..... 10**

6.1 Radar Unit ..... 12
6.2 Environmental ..... 12
6.3 Physical ..... 13

**7. Installation ..... 15**

7.1 Site Selection ..... 15
7.2 Sensor Alignment ..... 15
7.2.1 Vertical ..... 15
7.2.2 Azimuth ..... 16
7.3 Instrument Housing Adjustment ..... 16
7.4 Wiring ..... 16
7.4.1 Datalogger Connection ..... 16
7.4.2 Multiple Sensors Connection ..... 17
7.4.3 Built-in Self Test (BIST) ..... 17
7.5 Programming ..... 17
7.5.1 CRBasic ..... 17
7.5.1.1 Example Program ..... 18
7.5.2 Edlog ..... 19
7.5.2.1 Example Program ..... 19

**8. Diagnostics, Repair, and Maintenance ..... 20**

8.1 Testing Procedure ..... 20
8.1.1 Start Measurement Command ..... 21
8.1.2 Check Unit Response ..... 22
8.1.3 Check for Valid Data ..... 22
8.1.4 Cyclic Redundancy Check ..... 23
8.1.4.1 Check CRC for Valid Data ..... 23
8.1.5 Get Units ..... 23

8.1.6 Get Water Conditions ..... 23
8.1.7 Get Power Operation Mode ..... 24
8.2 Diagnostics and Repair ..... 24
8.2.1 No Measured Value Available — Error E013 ..... 24
8.2.2 No Measured Value Available — Error E041, E042, E043 ..... 24
8.2.2.1 Exchange Electronics Module ..... 25
8.3 Maintenance ..... 26

## *Appendices*

**A. Replacing the Cable ..... A-1**

**B. SDI-12 Commands/ Changing Settings ..... B-1**

B.1 SDI-12 Command Descriptions ..... B-2
B.1.1 Start False Echo Learn ..... B-2
B.1.2 Set Water Stage ..... B-3
B.1.3 Query/Set the Address ..... B-3
B.1.4 Set Units ..... B-4
B.1.5 Set Water Conditions ..... B-4
B.1.6 Set Power Operation Mode ..... B-5
B.2 Using Terminal Emulator and a Datalogger to Send Commands ..... B-6
B.2.1 SDI-12 Transparent Mode ..... B-6
B.2.2 CR200(X) Series Datalogger Example ..... B-6
B.2.3 CR1000 Datalogger Example ..... B-7
B.2.4 CR10X Datalogger Example ..... B-8
B.2.5 CR10X-PB Table-Based Datalogger Example ..... B-9

**C. FCC/IC Equipment Authorization (USA/Canada only) ..... C-1**

## *Figures*

4-1. Polarization markings (see Table 4-4 for label descriptions) ..... 4
5-1. CS475, CS476, and CS477 ..... 9
5-2. Components and hardware (see Table 5-1 for description of labels) ..... 10
6-1. Reference line for measurement range ..... 11
6-2. CS475 dimensions ..... 13
6-3. CS476/CS477 dimensions ..... 14
8-1. Changing the electronics (see Table 8-5 for label descriptions) ..... 26
A-1. Connecting the instrument housing (see Table A-1 for description of labels) ..... A-2
B-2. SDI-12 transparent mode on CR200(X)-series datalogger using control port C1/SDI12 and changing SDI-12 address from 0 to 1 ..... B-7
B-3. SDI-12 transparent mode on CR1000 datalogger using control port 1 and changing SD1-12 address from 3 to 1 ..... B-8
B-4. SDI-12 transparent mode on CR10X datalogger using control port 1 and changing SDI-12 address from 0 to 1 ..... B-9
B-5. SDI-12 transparent mode on CR10X-PB table-based datalogger using control port 1 and changing SDI-12 address from 0 to 1 .. B-10

## *Tables*


4-1. Default Settings ..... 2
4-2. Radiation Beam Spread for CS475 (10° Beam Angle) ..... 3
4-3. Radiation Beam Spread for CS476/CS477 (8° Beam Angle) ..... 3
4-4. Description of Polarization Markings Labels ..... 4
4-5. Example of a Start False Echo Learn Command ..... 5
4-6. Example for Setting Water Stage ..... 5
5-1. Description of Components and Hardware Labels ..... 10
7-1. Wiring Diagram ..... 17
7-2. SDI-12 Command Codes ..... 18
8-1. Example of Start Measurement Command ..... 21
8-2. Acknowledge Active Command ..... 22
8-3. Send Identification Command ..... 22
8-4. Checking CRC Example ..... 23
8-5. Description of Changing the Electronics Labels ..... 26
A-1. Description of Instrument Housing Labels ..... A-2
B-1. SDI-12 Commands ..... B-2
B-2. SDI-12 Command for Querying the Address ..... B-3
B-3. Example of Setting Address ..... B-4
B-4. Example of Setting Units ..... B-4
B-5. Example for Setting Water Conditions ..... B-5
B-6. Example for Setting Power Operation Mode ..... B-5

# *CS475, CS476, and CS477 Radar Water Level Sensor*

## 1. Introduction

The CS475, CS476, and CS477 are radar-ranging sensors that monitor the water level of rivers, lakes, tidal seas, and reservoirs. They output a digital SDI-12 signal to indicate distance and stage. Many of our dataloggers can read the SDI-12 signal.

Before using these radar sensors, please study

- Section 2, *Cautionary Statements*
- Section 3, *Initial Inspection*
- Section 4, *Quickstart*

## 2. Cautionary Statements

- Follow country-specific installation standards, prevailing safety regulations, accident prevention rules, and this manual's safety instructions.
- Depending on the model, the emitting frequencies of these radar sensors are either in the C or K band range. Their low transmitting power is well below the internationally permitted limits. When used correctly, the radar sensors present no danger to people.
- Do not attempt to install the sensor unless you are qualified to perform the installation.
- Care should be taken when opening the shipping package to not damage or cut the cable jacket. If damage to the cable is suspected, consult with a Campbell Scientific applications engineer.
- Handle the sensor carefully, since it is a precision instrument.
- Since the sensor is commonly installed over water from tall structures, use appropriate safety equipment such as a safety harness or a life preserver when installing or performing maintenance on the sensor.
- It is the responsibility of the user to ensure that the sensors are maintained and functioning properly.
- The sensor is designed for safe operations in accordance with the current technical, safety, and ANSI standards.

# 3. Initial Inspection

When unpacking the equipment, do the following:

- Unpack the unit in a clean, dry area.
- Inspect the equipment for any damage that occurred during shipping or storage.
- If the equipment is damaged, file a claim against the carrier and report the damage in detail.

# 4. Quickstart

This Quickstart uses the default settings (see Table 4-1), which are used in most circumstances.

**Table 4-1. Default Settings**

| Setting | Default |
|---|---|
| SDI-12 Address | 0 (change only if two sensors are connected to the same port; valid addresses are 0 through 9, A through Z, and a through z; see Appendix B.1.3, *Query/Set the Address)* |
| Units of Measure | 1 = feet (see Appendix B.1.4, *Set Units*) |
| Water Conditions | 1 = smooth (typical peak to trough of wave ≤4 inches; see Appendix B.1.5, *Set Water Conditions*) |
| Power Operation Mode | 1 = on (sensor is always on until new power operation mode command received; see Appendix B.1.6, *Set Power Operation Mode*) |

**NOTE** Detailed information about all of the settings and information on changing the settings are provided in Appendix B.

## 4.1 Step 1 — Mount and Align the Sensor

1. Choose an appropriate site away from obstructions and over the smoothest part of the water (see Section 7.1, *Site Selection*).
2. Centre the sensor beam a minimum of 2.5 m from any obstruction in the measurement range. Obstructions to be aware of include excessive waves, splashing, pipes, wires, and logs. Note that the radiation beam spreads as it leaves the sensor (see Table 4-2 and Table 4-3).

**NOTE** Usually the beam path is 10° for the CS475, and 8° for the CS476/CS477.

| Table 4-2. Radiation Beam Spread for CS475 (10° Beam Angle) | |
|---|---|
| **Distance in Metres** | **Diameter of Footprint in Metres** |
| 1 | 0.18 |
| 5 | 0.87 |
| 10 | 1.76 |
| 15 | 2.64 |
| 20 | 3.53 |

| Table 4-3. Radiation Beam Spread for CS476/CS477 (8° Beam Angle) | |
|---|---|
| **Distance in Metres** | **Diameter of Footprint in Metres** |
| 1 | 0.14 |
| 5 | 0.70 |
| 10 | 1.41 |
| 15 | 2.11 |
| 20 | 2.81 |
| 30 | 4.216 |
| 70 (CS477 only) | 9.84 |

3. Securely mount the sensor.

4. Use a user-supplied bubble level or the 25619 bubble level to make certain the antenna horn is aligned within 1° of vertical. The cap needs to be removed when using the 25619. If the antenna is not vertical, a trigonometric measurement error can occur with respect to the water. The maximum range is reduced because of the off-axis return signal.

5. Orient the sensor such that one of its polarization markings is aligned towards the wall or pier (see Figure 4-1 and Table 4-4).




*Figure 4-1. Polarization markings (see Table 4-4 for label descriptions)*

**Table 4-4. Description of Polarization Markings Labels**

| | Sensor | Description |
|---|---|---|
| 1 | CS475 | Polarization marks are designated by the mounting loop screws. |
| 2 | CS476/CS477 | Polarization mark is machine-tooled. |

## 4.2 Step 2 — Do a False Echo Learn Command

**NOTE** The 25616, *Adjustment/Display Module*, or the terminal emulator in LoggerNet or PC400 can be used to enter SDI-12 commands. Appendix B.2, *Using Terminal Emulator and a Datalogger to Send Commands*, describes entering commands using the terminal emulator.

Do a *Start False Echo Learn* command followed by a *Send Data* command (see Table 4-4). To start false echo learn, do the **aXSFEL+nnn.nnn!** command (where nnn.nnn = the actual distance to the water) followed by the **aD0!** (*Send Data*) command. Table 4-5 shows an example of the command and response.

Any echo occurring 0.5 m (1.6 ft) short of the distance you entered will be considered noise.

Appendix B describes this command in further detail.

| Table 4-5. Example of a Start False Echo Learn Command | |
|---|---|
| **Initial Command** | **Response** |
| **0XSFEL+2.500!**<br>Where (from left to right),<br>0—sensor's address;<br>2.500—the water surface distance. | **02001<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>200—the amount of time (in seconds) that you must wait before sending the send data command;<br>1—the number of values that will be placed in the buffer. |
| **Subsequent Command** | **Response** |
| **0D0!**<br>Where the first zero is the sensor address.<br>This is the send data command. | **0+2.500<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>2.500—the water surface distance. |

## 4.3 Step 3 — Do a Set Water Stage Command

**NOTE** The 25616, *Adjustment/Display Module*, or the terminal emulator in LoggerNet or PC400 can be used to enter SDI-12 commands. Appendix B.2, *Using Terminal Emulator and a Datalogger to Send Commands*, describes entering commands using the terminal emulator.

Do a *Set Water Stage* command followed by a *Send Data* command (see Table 4-6). To set the water stage, do an **aXSS+nnn.nnn!** command (where nnn.nnn = the initial water depth) followed by the **aD0!** (*Send Data*) command. Table 4-6 shows an example of the command and response for entering this setting.

Appendix B describes this command in further detail.

| Table 4-6. Example for Setting Water Stage | |
|---|---|
| **Initial Command** | **Response** |
| **0XSS+7.010!**<br>Where (from left to right),<br>0—sensor's address;<br>7.010—the initial water depth value used to calculate subsequent stage measurements. | **00011<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>001—the amount of time (in seconds) that you must wait before sending the send data command;<br>1—the number of values that will be placed in the buffer. |

| Subsequent Command | Command Response |
|---|---|
| **0D0!**<br>Where the first zero is the sensor address.<br>This is the send data command. | **0+7.010<cr><If>**<br>Where (from left to right),<br>0—sensor's address;<br>7.010—the initial water depth value used to calculate subsequent stage measurements. |

## 4.4 Step 4 — Use SCWin Short Cut to Program Datalogger and Generate Wiring Diagram

1. Open Short Cut and click on **New Program**.




2. Select a datalogger and scan interval.



3. Under **Generic Measurements**, select **SDI-12 Sensor** then click the **right arrow** to add it to the list of sensors to be measured.




4. A properties window will appear. In this window, enter *Stage* and *Feet* for the **First Result**; *Distance* and *Feet* for the **Second Result**, and *ErrorCode* for the **Third Result**.



5. Choose the outputs and then select **Finish**.




6. Wire according to the wiring diagram generated by Short Cut.




# 5. Overview

The CS475, CS476, and CS477 emit short microwave pulses and measure the elapsed time between the emission and return of the pulses. The elapsed time measurement is used to calculate the distance between the sensor face and the target (for example, water, grain, slurry). The distance value can be used to determine depth.

These radar sensors output a digital SDI-12 signal to indicate distance and stage. This output is acceptable for recording devices with SDI-12 capability including Campbell Scientific dataloggers.

Three sensor models are available that differ in their measurement range and accuracy. The CS475 can measure distances up to 65 feet with an accuracy of ±0.2 inches; the CS476 can measure up to 98 feet with an accuracy of ±0.1 inches; and the CS477 can measure up to 230 feet with an accuracy of ±0.6 inches.

The –L after the model name indicates that the cable length is user specified.

The cable can terminate in:

- Pigtails that connect directly to a Campbell Scientific datalogger (option –PT).
- Connector that attaches to a prewired enclosure (option –PW). Refer to *www.campbellsci.com/prewired-enclosures* for more information.

*Figure 5-1. CS475, CS476, and CS477*

## 5.1 Components and Hardware

The radar sensor consists of an integrated microwave transmitter and sensor together with a horn antenna (see Figure 5-2 and Table 5-1). The horn antenna serves to focus the transmitted signal and to receive the reflected echo. A built-in SDI-12 interface provides data processing and SDI-12 communications with the datalogger.




*Figure 5-2. Components and hardware (see Table 5-1 for description of labels)*

**Table 5-1. Description of Components and Hardware Labels**

| | |
|---|---|
| (A) | CS475 |
| (B) | CS476 or CS477 |
| 1 | Mounting Loop |
| 2 | PULS Housing Side Cap |
| 3 | PULS Housing Cap |
| 4 | PULS Unit Secondary 1/2” NPT Cable Port, Primary Port on Opposite Side |
| 5 | PULS Instrument Horn |
| 6 | 5/8” Hex Head Cap Screw and Lock Washer |
| 7 | Swivel Mounting Flange |

# 6. Specifications

**Features:**

- FCC compliant
- Ideal for areas where submersed sensors can be damaged due to corrosion, contamination, flood-related debris, lightning, or vandalism
- Compatible with most Campbell Scientific dataloggers (including the CR200(X) series)

- Low maintenance—no moving parts significantly reduces maintenance cost and time
- Low power consumption
- Rugged enough for harsh environments—NEMA rated 4X
- Individual FCC license not required

**Compatibility**

**Dataloggers:** CR200(X) series
CR800 series
CR1000
CR3000
CR5000
CR500
CR510
CR10(X)
CR23X

**Measurement Range** (see Figure 6-1)

**CS475**: 50 mm to 20 m (2 in to 65 ft)
**CS476**: 50 mm to 30 m (2 in to 98 ft)
**CS477**: 400 mm to 70 m (16 in to 230 ft)




*Figure 6-1. Reference line for measurement range*

**Accuracy**

**CS475:** ±5 mm (±0.2 in)
**CS476:** ±3 mm (±0.1 in)
**CS477:** ±15 mm (±0.6 in)

**Resolution:** 1 mm (0.0033 ft)

**Output Protocol:** SDI-12

## 6.1 Radar Unit

| | |
|---|---|
| **Frequency:** | ~26 GHz |
| **Electromagnetic Compatibility:** | Emission to EN 61326;<br>Electrical Equipment Class B |
| **Pulse Energy:** | 1 mW maximum |
| **Beam Angle** | |
| **CS475:** | 10° (3-in dia horn) |
| **CS476, CS477:** | 8° (4-in dia horn) |
| **Power Requirements** | |
| **Input Voltage:** | 9.6 to 16 Vdc |
| **Surge Protection:** | 1.5 KVA |
| **Typical Current Drain with 12 V Power Supply** | |
| **Sleeps:** | 4.7 mA |
| **Measurement:** | 14 mA |

## 6.2 Environmental

| | |
|---|---|
| **Operating Temperature Range:** | –40° to +80°C |
| **Storage Ranges** | |
| **Temperature:** | –40° to +80°C |
| **Relative Humidity:** | 20% to 80% RH |
| **Temperature Sensitivity:** | average TK: 2 mm/10 K,<br>max 5 mm over the entire<br>temperature range of<br>–40°to +80°C |
| **Vibration Resistance:** | Mechanical vibrations with 4 g<br>and 5 to 100 Hz |

## 6.3 Physical

See Figure 6-2 and Figure 6-3 for dimensions.

**Rating:** NEMA 4x

**Housing Material:** Aluminium, coated IP66/68

**Horn Material:** 316L stainless steel

**Weight**

**CS475:** 2 kg (4 lb)

**CS476/CS477:** 4.3 kg (9.4 lb)




*Figure 6-2. CS475 dimensions*




*Figure 6-3. CS476/CS477 dimensions*

# 7. Installation

Before installing the radar sensor, you must consider all the suggested guidelines for site and maintenance issues. Do not attempt to install the sensor unless you are qualified to perform the installation. The sensor is designed for safe operation in accordance with the current technical, safety, and ANSI standards.

**CAUTION** If you are uncertain of the safe installation and operation of this unit, read and understand all the instructions included in this manual before attempting any installation or operation.

## 7.1 Site Selection

1. Mount the sensor high enough to prevent submersion during flooding conditions.

**WARNING** **Since the sensor is commonly installed over water from tall structures, use appropriate safety equipment such as a safety harness or a life preserver when installing or performing maintenance on the sensor.**

2. Install the sensor above the smoothest part of the water surface.

**NOTE** The smoothest part of the water surface is typically found halfway between bridge piers. However, bridges with long spans between the piers experience more vibration. For these bridges, vibration can be minimized by mounting the sensor a quarter to a third of the distance to the next pier.

3. Avoid mounting near horizontal structural surfaces such as beams, brackets, and sidewall joints because these surfaces reflect a strong signal. If these structures cannot be avoided, use the *False Echo Learn* command to map out the interfering structures in the beam profile (see Appendix B.1.1, *Start False Echo Learn*).

4. Center the sensor beam a minimum of 2.5 m from any obstruction in the measurement range. Obstructions to be aware of include excessive waves, splashing, pipes, wires, and logs. Note that the radiation beam spreads as it leaves the sensor (see Table 4-2 and Table 4-3 in Section 4, *Quickstart*).

**NOTE** Usually the beam path is 10° for the CS475, and 8° for the CS476/CS477.

5. Be aware that bridges contract and expand with temperature changes. Traffic loads or trucks can also cause changes to the bridge height.

6. Do not install the sensor where submerged obstructions such as rocks or bridge piers can distort or disturb water level.

## 7.2 Sensor Alignment

### 7.2.1 Vertical

Use a user-supplied bubble level or the 25619 bubble level to make certain the antenna horn is aligned within 1° of vertical. The cap needs to be removed when using the 25619. If the antenna is not vertical, a trigonometric measurement error

can occur with respect to the water. The maximum range is reduced because of the off-axis return signal.

### 7.2.2 Azimuth

The sensor's radar beam is polarized so it emits radar waves in an elliptical or football shape. You should orient the unit so the lobes are parallel to, and do not intersect, the pier when installing on a wall or close to a bridge pier. The radar housing has a large hex nut on its mount stem. Two drill marks below the hex nut indicate which direction the lobes extend the least. Orient the sensor such that one of the marks is aligned towards the wall or pier (see Figure 4-1 and Table 4-4 in Section 4, *Quickstart*).

## 7.3 Instrument Housing Adjustment

After mounting, you can rotate the housing up to 350° to simplify access to the conduit entry and terminal compartment. Proceed as follows to rotate the housing to the desired position:

1. Loosen the set screw on the housing.
2. Rotate the housing as desired.
3. Tighten the set screw.

## 7.4 Wiring

### 7.4.1 Datalogger Connection

As shipped from Campbell Scientific, the sensor is fitted with a cable for connection with the datalogger. Appendix A describes replacing this cable.

Connections to Campbell Scientific dataloggers are given in Table 7-1. The sensor should be wired to the channels shown on the wiring diagram created by Short Cut.

**CAUTION** Connect the wires in the order shown in Table 7-1.

| Table 7-1. Wiring Diagram | | | | | | |
|---|---|---|---|---|---|---|
| **Colour** | **Description** | **CR800, CR850, CR1000, CR3000,** | **CR10(X), CR510, CR500** | **CR23X** | **CR5000** | **CR200(X)** |
| White | SDI-12 Signal | Odd Numbered Control Port (C1, C3…) | Odd Numbered Control Port (C1, C3…) | Odd Numbered Control Port (C1, C3…) | SDI-12 | C1/SDI-12 |
| Clear | Chassis Ground | ⏚ | G | ⏚ | ⏚ | ⏚ |
| Red | +12V (Power Supply for Sensor) | 12V | 12V | 12V | 12V | Battery+ |
| Black | Ground | G | G | ⏚ | G | G |

### 7.4.2 Multiple Sensors Connection

To use more than one probe per datalogger, you can either connect the different probes to different SDI-12 compatible ports on the datalogger or change the SDI-12 addresses of the probes and let them share the same connection. Using the SDI-12 address minimizes the use of ports on the datalogger and also allows probes to be connected in a daisy-chain fashion which can minimize cable runs in some applications.

### 7.4.3 Built-in Self Test (BIST)

After connecting the sensor to the datalogger's power terminals, the sensor performs a BIST (built-in self test) for approximately 80 seconds (factory default). During this self-check, an internal check of the electronics occurs.

## 7.5 Programming

**NOTE** This section is for users who write their own datalogger programs. A datalogger program to measure this sensor can be created using Campbell Scientific's Short Cut Program Builder software. These sensors are not listed in the sensor list in Short Cut. Instead, select SDI-12 sensor under General Measurements (see Section 0, *Step 4 — Use SCWin Short Cut to Program Datalogger and Generate Wiring Diagram*, for more information about using Short Cut). You do not need to read this section to use Short Cut.

The radar sensor's output is measured using a standard SDI-12 instruction to read the data from an SDI-12 sensor. If using the sensor with other SDI-12 recorders, please refer to your system's documentation. Further details of the SDI-12 commands can be found in Appendix B and at: *www.sdi-12.org*.

### 7.5.1 CRBasic

Dataloggers that are programmed with CRBasic include the CR200(X) series, CR800, CR850, CR1000, CR3000, and CR5000. These dataloggers use the **SDI12Recorder()** instruction to read the sensor. The **SDI12Recorder()** instruction should only be ran in the sequential mode.

The values returned from the **SDI12Recorder()** instruction are different depending on the SDI-12 measurement command issued. The **SDI12Recorder()** instruction sends the command specified by the *SDI12Command* parameter as *(address)SDI12Command!*.

**SDI12Recorder(***Dest, SDIPort, SDIAddress, "SDICommand", Multiplier, Offset***)**

The **SDI12Recorder()** instruction has the following parameters:

*Dest* The *Dest* parameter is a variable in which to store the results of the measurement. *Dest* must have enough elements to store all the data that is returned by the sensor or a 'variable out of range' error will result during the execution of the instruction.

*SDIPort* The *SDIPort* parameter is the port to which the SDI-12 sensor is connected. A numeric value is entered:

| Code | Description |
|---|---|
| 1 | Control Port 1 |
| 3 | Control Port 3 |
| 5 | Control Port 5 |
| 7 | Control Port 7 |

*SDIAddress* The *SDIAddress* parameter is the address of the sensor that will be affected by this instruction. Valid addresses are 0 through 9, A through Z, and a through z. Alphabetical characters should be enclosed in quotes (for example, "0").

*SDICommand* The *SDICommand* parameter is used to specify the command strings that will be sent to the sensor. The command should be enclosed in quotes. Table 7-2 shows the specific SDI-12 Command Codes and their returned values.

**Table 7-2. SDI-12 Command Codes**

| SDI12 Measurement Command | Returned Values |
|---|---|
| **M!** | 1) Stage in metres or feet<br>2) Distance in metres or feet<br>3) Error Code (see Section 8, *Diagnostics, Repair, and Maintenance*) |

#### *7.5.1.1 Example Program*

```
'CR1000 Series Datalogger

'Declare the variable for the water level measurement

Public CS475(3)

'Rename the variable names
Alias CS475(1)=Stage
Alias CS475(2)=Distance
Alias CS475(3)=Error_Code

'Define a data table for 60 minute maximum and minimums
DataTable (Hourly,True,-1)
  DataInterval(0,60,Min,10)
  Maximum(1,Distance,FP2,0,0)
```

```
  Minimum(1,Distance,FP2,0,0)
  Average(1,Distance,FP2,False)
  StdDev(1,Distance,FP2,False)
  Maximum(1,Stage,FP2,0,0)
  Minimum(1,Stage,FP2,0,0)
  Average(1,Stage,FP2,False)
  StdDev(1,Stage,FPs,False)
  Sample (1,Error_Code,UINT2)
EndTable

'Read sensor every 60 seconds
BeginProg
  Scan(60,sec,1,0)

  'Code for SDI-12 measurements:
  SDI12Recorder(CS475,1,0,"M!",1,0)

  'Call the data table:
  CallTable(Hourly)

NextScan

EndProg
```

## 7.5.2 Edlog

Dataloggers that are programmed with Edlog include the CR500, CR510, CR10(X), and CR23X. These dataloggers use Instruction 105 to read the sensor.

Instruction 105 allows data to be collected from the radar sensor; each sensor requires a separate Instruction 105.

Instruction 105 has the following parameters:

Parameter 1 — Address. Valid addresses are 0 through 9; 65 through 90 (decimal value for ASCII upper-case letters); and 97 through 122 (decimal values for ASCII lower-case letters).

Parameter 2 — Command. Refer to the Edlog help for the command codes used with this instruction.

Parameter 3 — Port. Enter the datalogger port in which the datalogger is connected.

Parameter 4 — Location. Enter the input location in which to store the results.

Parameter 5 — Multiplier

Parameter 6 — Offset

**NOTE** Edlog allocates only one of the input locations needed for this instruction. Three input locations are required for this sensor. The additional input locations must be inserted manually using the Input Location Editor. For information on manually inserting input locations, refer to Manually Inserting Input Locations in the Edlog help.

### *7.5.2.1 Example Program*

Below is a portion of a CR10X program that measures the radar sensor.

**NOTE** The instructions below do not store data in final storage. Instruction 92, Instruction 77 and processing instructions such as Instruction 70 are required to store the data permanently.

```
;{CR10X}
;
*Table 1 Program
01:    60            Execution Interval (seconds)

1: SDI-12 Recorder (P105)
   1:  0             SDI-12 Address
   2:  0             Start Measurement (aM0!)
   3:  1             Port ;this is where the white wire is connected
   4:  1             Loc[Data_1 ]
   5:  1.0           Mult
   6:  0.0           Offset

*Table 2 Program
   02:  0.000        Execution Interval (seconds)

*Table 3 Subroutines

End Program
```

After Instruction 105 is executed, the input location called "Data_1" will hold the measured stage, reported in feet or metres (depending on the Unit of Measure setting). The input location called Data_2 will hold the distance measurement, reported in feet or metres (depending on the Unit of Measure setting). The input location called Data_3 will hold the error code; an error code of 0 indicates that the sensor is functioning properly (see Section 8, *Diagnostics, Repair, and Maintenance*).

Note that Port 1 specifies that the SDI-12 data line is to be connected to the Port C1.

# 8. Diagnostics, Repair, and Maintenance

## 8.1 Testing Procedure

The test procedures for the sensor require the following steps:

1. Double check all wiring connections.

2. Connect the sensor to your datalogger and apply +12V power.

3. Compare the Output Stage versus the Actual Stage using the *Start Measurement* command followed by the *Send Data* command (see Section 8.1.1, *Start Measurement Command*).

4. Send the *Acknowledge Active* command (see Section 8.1.2, *Check Unit Response*). This command is used to check the presence of the sensor on the bus. Only the address is sent back in response.

5. Send the *Identification* command (see Section 8.1.3, *Check for Valid Data*).

6. Send the *Start Verification* command followed by the *Get Data* command (see Section 8.1.4, *Cyclic Redundancy Check*).

7. Use the *Get Unit* command to ensure the units are what you want (see Section 8.1.5, *Get Units*).

8. Use the *Get Water Condition* command to ensure that the water condition fit the body of water you are monitoring (see Section 8.1.6, *Get Water Conditions*).

9. Use the *Get Power Operation Mode* to ensure that the power mode is what you want (see Section 8.1.7, *Get Power Operation Mode*).

10. Use the *False Echo Learn* command if you encounter a problem that could be caused by noise (see Section 4.2, *Step 2 — Do a False Echo Learn Command*).

### 8.1.1 Start Measurement Command

**NOTE** The 25616, *Adjustment/Display Module*, or the terminal emulator in LoggerNet or PC400 can be used to enter this command. Appendix B.2, *Using Terminal Emulator and a Datalogger to Send Commands*, describes entering commands using the terminal emulator. The *Start Measurement* command is also used in CRBasic or Edlog programming. Refer to the Edlog help for the appropriate command code entry.

The **aM!** command requests measurement values from the sensor. This command is always followed by the **aD0!** (*Send Data*) command (see Table 8-1). As a response of the *Send Data* command, the following information will be returned.

- Stage—the water level as measured in metres or feet. This measurement is calculated using the Water Stage Setting and the Units setting.

- Distance—the distance between the sensor and water surface. This value will be reported in either metres or feet, depending on the Units setting.

- Diagnostic Values—an error code. For example, Code 0 = OK, Code 13 = error E013 (see Section 8.2, *Diagnostics and Repair*).

**Table 8-1. Example of Start Measurement Command**

| **Initial Command** | **Response** |
|---|---|
| **0M!**<br>Where zero is the sensor address. | **00023<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>002—the amount of time (in seconds) that you must wait before sending the send data command;<br>3—the number of values that will be placed in the buffer. |
| **Subsequent Command** | **Response** |

| | |
|---|---|
| **0D0!**<br>Where the first zero is the sensor address. | **0+100.050+25.000+0<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>100.050—the stage in metres or feet;<br>25.000—the distance in metres or feet;<br>0—error code. |

### 8.1.2 Check Unit Response

The *Acknowledge Active* command is used to check the presence of the sensor on the bus (see Table 8-2).

**Table 8-2. Acknowledge Active Command**

| Initial Command | Response |
|---|---|
| **a!** | **a<cr><lf!>**<br>Only the address is sent back in response. |

### 8.1.3 Check for Valid Data

The **aI!** command gets the following identification information in response to sending **aI!** (see Table 8-3).

- Compatibility level: Version of SDI-12 protocol version; for example, 1.3.
- Manufacturer's Name: VEGA
- Manufacturer's Model Number: PS61 (CS475), PS62 (CS476), or PS63 (CS477)
- Three Digit Firmware Version Number.
- Eight Digit Serial Number of Sensor.

**Table 8-3. Send Identification Command**

| Initial Command | Response |
|---|---|
| **aI!** | **a13VEGAbbbbPS6233212345678<cr><lf>**<br>Where (from left to right),<br>a—sensor address;<br>13—SDI-12 compatibility number;<br>VEGA = Manufacturer's Name;<br>PS62 = Manufacturer's Model Number;<br>3.32 = Sensor Version Number;<br>Serial Number = 12345678. |

## 8.1.4 Cyclic Redundancy Check

A cyclic redundancy check (CRC) is used to produce and send a small, fixed-size checksum of a larger block of data to the datalogger. This checksum detects errors after transmission or storage. The CRC is computed and added before any transmission or storage. The CRC is also authenticated by the recipient, after the transmission, to confirm that no alterations occurred. CRCs are very good at identifying errors caused by noise in transmission channels.

### *8.1.4.1 Check CRC for Valid Data*

The **aV!** command requests three verification values from the sensor. This command is always followed by the **aD0!** (*Send Data*) command.

The verification values that will be returned are:

- CRC check (error check)—values are 0 (OK) or 1 (failed)
- SDI-12 Radar firmware version number
- HART Sensor firmware version

Table 8-4 shows an example of checking the CRC.

**Table 8-4. Checking CRC Example**

| **Initial Command** | **Response** |
|---|---|
| **0V!**<br>Where 0 is the sensor's address. | **00013<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>001—the amount of time (in seconds) that you must wait before sending the send data command;<br>3—the number of values that will be placed in the buffer. |
| **Subsequent Command** | **Response** |
| **0D0!**<br>Where the first zero is the sensor's address. | **0+0+1610000+3320000<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>0—CRC check (0 = OK);<br>1610000—adapter version (1.61.00.00);<br>3320000—sensor version (3.32.00.00). |

## 8.1.5 Get Units

Use the **aXGU!** command to get the current units setting of the sensor. If the units are feet, a 1 will be returned, and if the units are metres, a 0 will be returned.

## 8.1.6 Get Water Conditions

The **aXGWC!** command returns the current setting of the water conditions. Possible water conditions are:

1 = smooth (default)

2 = medium

3 = rough

0 = undefined (custom settings)

### 8.1.7 Get Power Operation Mode

The **0XGPOM!** command provides the current power operation mode setting of the sensor.

## 8.2 Diagnostics and Repair

The radar sensor is extremely reliable, but problems can occur during operation. Most of these problems are caused by the following:

- Sensor
- Environmental conditions
- Power supply
- Signal processing

When you encounter a problem with the radar sensor, check the error messages from the aM!, followed by the aD0! command to help evaluate the issue.

**NOTES**

1. During the initial power up or resumption of supply voltage to the sensor, some SDI-12 commands, such as the **I** command, will not yield the expected responses.

2. A typical response to the **aD0!** command results in a response of **108003** where approximately 80 seconds is the required time to complete the BIST (Built In Self Test) of the instrument. After power up is complete, normal SDI-12 communication starts.

### 8.2.1 No Measured Value Available — Error E013

If you are unable to find a measured value, check the following:

- Sensor in boot phase
- Update the *Start False Echo Learn* (**aXSFEL**).

### 8.2.2 No Measured Value Available — Error E041, E042, E043

If you have a hardware error or have defective electronics, try cycling the power to the sensor. If the sensor recovers, no further steps are required. If the sensor does not recover, do one of the following:

- Exchange the electronics module (see Section 8.2.2.1, *Exchange Electronics Module*)
- Return the equipment for repair (an RMA number is required)

#### 8.2.2.1 Exchange Electronics Module

If you do not have an electronics module onsite, order one from Campbell Scientific.

The electronics module is replaced by doing the following steps (see Figure 8-1 and Table 8-5):

1. Unscrew the housing cap (cap is not shown in Figure 8-1).
2. Remove all wires that are attached or plugged into the electronics and note their location for reassembly.
3. Loosen the two screws securing the electronics to the housing (3 in Figure 8-1). These screws are captive screws and will remain nested with the electronics.
4. Gently remove the electronics from the housing (4 in Figure 8-1).

**NOTE** Some friction is normal when removing the electronics because a seal is between the electronics and the lower portion of the housing.

5. Replace the electronics with a new module.

**NOTE** Make sure the two (2) screws holding the electronics module in are tight, but do not over tighten. Over tightening these screws can strip the threads.

6. Tighten the two screws to secure the electronics to the housing (3 in Figure 8-1).
7. Re-assemble all wires that were originally attached or plugged into the electronics.
8. Tighten the housing cap.




*Figure 8-1. Changing the electronics (see Table 8-5 for label descriptions)*

**Table 8-5. Description of Changing the Electronics Labels**

| | **Description** |
|---|---|
| 1 | Red Wire |
| 2 | Housing Top View |
| 3 | Screws to Secure Electronics to Housing |
| 4 | Electronics |
| 5 | Housing Side View |

## 8.3 Maintenance

The sensors are maintenance free under normal operation.

# Appendix A. Replacing the Cable

The sensor is fitted with a cable for connection to the datalogger. The following procedure is for replacing the original cable (see Figure A-1 and Table A-1).

1. Unscrew the housing side compartment screw cap.
2. Loosen the cord grip on the cable entry.
3. Remove approximately 4 inches (10 cm) of the cable mantle.
4. Strip approximately 0.4 inches (1 cm) of the insulation from the end of the individual wires.
5. Insert the cable into the sensor through the cable entry.
6. Lift the opening levers of the terminals with a screwdriver.
7. Insert the wire ends into the open terminals.
    - Connect the Power Supply +12 Vdc to the terminals marked 1 (+).
    - Connect the Power Supply Ground to the terminals marked 2 (–).
    - Connect the Data Line to the terminals marked 3 (data).
8. Press the opening lever of the terminal down. You will hear the terminal spring closed.
9. Check that the wires are firmly connected in the terminal by lightly pulling on them.
10. Connect the screen to the internal ground terminal and the external ground terminal to potential equalization (ground).
11. Tighten the cord grip on the cable entry. The seal ring must completely encircle the cable.
12. Place the housing side compartment screw cap on and tighten to ensure a mechanical seal.




*Figure A-1. Connecting the instrument housing (see Table A-1 for description of labels)*

**Table A-1. Description of Instrument Housing Labels**

| Connections | Description |
|---|---|
| (A) | Side Chamber SDI-12 Wiring |
| (B) | Top Chamber Inner Housing Connections |
| (C) | Typical SDI-12 Network Configuration |
| (D) | DIS61 (Optional) (Reference V-2799S0) |
| 1 | Inner Housing Connections (Modular Plug Mounted in Dual Chamber Housing), Plugs into Back of SDI-12 Board |
| 2 | SDI-12 Data |
| 3 | Ground Connection |
| 4 | Data Acquisition Device |
| 5 | Serial Data Line |
| 6 | 12V (–) Ground |
| 7 | 12V (+) Line |
| 8 | SDI-12 Sensor #1 |
| 9 | SDI-12 Sensor #2 |
| 10 | Ground Connection |
| 11 | To Instrument |
| 12 | Remote Display |
| 13 | Ground Connection |
| 14 | Digital Output (To Optional Remote Display) |
| 15 | Plug for Laptop Connection |
| 16 | Remote Display |
| 17 | Red |
| 18 | Other |

# Appendix B. SDI-12 Commands/ Changing Settings

The SDI-12 commands are entered using the 25616, *Adjustment/Display Module*, or the terminal emulator in LoggerNet or PC400 (see Appendix B.2, *Using Terminal Emulator and a Datalogger to Send Commands*). These commands are also used in CRBasic or Edlog programming (see Section 7.5, *Programming*).

SDI-12 commands have three components:

*Sensor address (a)* – a single ASCII character, and is the first character of the command. The sensor address allows multiple sensors to be connected to a single control port. The default address is zero, and typically is only changed when multiple sensors are connected to the same port. Valid addresses are 1 to 9, A to Z, or a to z.

*Command body (e.g., M1)* – an upper case letter (the "command") followed by alphanumeric qualifiers.

*Command termination (!)* – an exclamation mark.

An active sensor responds to each command. Responses have several standard forms and terminate with <CR><LF> (carriage return – line feed). SDI-12 commands supported by the radar sensors are listed in Table B-1.

**Table B-1. SDI-12 Commands**

| Function | SDI-12 Command |
|---|---|
| Address Query | **?!** |
| Send Identification | **aI!** |
| Acknowledge Active | **a!** |
| Change Address | **aAb!**<br>Where a is the current address and b is the new address. |
| Start Verification | **aV!** |
| Start Measurement | **aM!** |
| Start Measurement and Request CRC | **aMC!** |
| Send Data | **aD0!...aD9!** |
| Additional Measurements | **aM1!...aM9!** |
| Additional Measurement and Request CRC | **aMC1!...aMC9!** |
| Start Concurrent Measurement | **aC!** |
| Start Concurrent Measurement and Request CRC | **aCC!** |
| Additional Concurrent Measurements | **aC1!...aC9!** |
| Additional Concurrent Measurements and Request CRC | **aCC1!...aCC9!** |
| Start False Echo Learn | **aXSFEL+n!**<br>*n* = distance necessary to clear the obstruction |
| Set Power n Operation Mode | **aXSPOM+n!**<br>*n* = 2 (auto), 1 (on), or 0 (off) |
| Get Power Operation Mode | **aXGPOM!**<br>2 = auto; 1=on; 0=off |
| Get Water Conditions | **aXGWC!**<br>n = 0 (auto), 1 (smooth) 2 (medium), or 3 (rough) |
| Set Water Conditions | **aXSWC+n!**<br>n = 0 (auto), 1 (smooth) 2 (medium), or 3 (rough)<br>Where n is the new water condition. |
| Set Water Stage | **aXSS+n!**<br>n = floating point number that is the initial stage or level of the water surface above the reference.<br>Where n is the new water stage. |
| Get Unit | **aXGU!**<br>0 = metres; 1=feet |
| Set Unit | **aXSU+n!**<br>n = 0 (meters) or 1 (feet)<br>Where n is the new unit of measurement. |
| Reset Sensor | **aXRS!**<br>0 = reset unsuccessful; 1=reset successful<br>Resets the sensor to its factory settings. |

# B.1 SDI-12 Command Descriptions

## B.1.1 Start False Echo Learn

The *Start False Echo Learn* command is an essential function during the start up of the sensor. It is also used during testing if a problem is encountered. The command allows the unit to learn about false echoes (noise) in the area. With the

*False Echo Learn* command, you enter the actual distance to the water surface, as measured in metres or feet, depending on the unit setting. The radar sensor then emits the short microwave pulses. Any echo occurring 0.5 m (1.6 ft) short of the distance you entered will be considered noise.

To start *False Echo Learn*, do the **aXSFEL+nnn.nnn!** command (where nnn.nnn = the actual distance to the water) followed by the **aD0!** (*Send Data*) command. Table 4-5 in Section 4, *Quickstart*, shows an example of the command and response.

## B.1.2 Set Water Stage

With the *Set Water Stage* command, you enter the initial depth of the water, and the sensor will automatically measure the distance between the sensor and the water surface. The water stage setting and the initial distance measurement are used to calculate subsequent water stage measurements. Correct stage measurements require that the water stage setting be in the same units as the Units of Measure setting. You can find out if the sensor is set to metres or feet by using the **aXGU!** (*Get Unit*) command.

To set the water stage, do an **aXSS+nnn.nnn!** command (where nnn.nnn = the initial water depth) followed by the **aD0!** (*Send Data*) command. Table 4-6 in Section 4, *Quickstart*, shows an example of the command and response for entering this setting.

## B.1.3 Query/Set the Address

Valid addresses are 0 to 9; A through Z; and a through z. The factory default address is set to 0. The address can be verified by sending the sensor the *Address Query* command (see Table B-2).

**Table B-2. SDI-12 Command for Querying the Address**

| Initial Command | Response |
|---|---|
| **?!** | **a<cr><lf>**<br>Where a is the current address of the sensor. |

Change the sensor's address by sending the sensor the **aAb!** command, where "a" is the original address and "b" is the new address. Table B-3 shows an example of the command and response for setting the address.

| Table B-3. Example of Setting Address | |
|---|---|
| **Initial Command** | **Response** |
| **0A1!**<br>Where 0 is the original address and 1 is the new address. | **1<cr><lf>**<br>The new address (1) is set in response. |

## B.1.4 Set Units

The distance measurement can be reported in feet (default) or metres. Change the units by first using the **aXSU+n!** command (where n = 1 (feet) or 0 (meters)) followed by the **aXGU!** (*Get Units*) command. Table B-4 shows an example of the command and response for changing this setting.

| Table B-4. Example of Setting Units | |
|---|---|
| **Initial Command** | **Response** |
| **0XSU+0!**<br>Where the first zero is the sensor address and the second zero sets the units to metres. | **00011<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>001—the amount of time (in seconds) that you must wait before sending another command;<br>1—the number of values that will be placed in the buffer. |
| **Subsequent Command** | **Response** |
| **0XGU!**<br>Where zero is the sensor address.<br>This is the get units command. | **0+0<cr><lf>**<br>Where the first zero is the sensor address and the second zero indicates that the units are now metres. |

## B.1.5 Set Water Conditions

The *Set Water Conditions* command adapts the sensor to different water conditions.

There are four different settings:

- 0 (custom setting)
- 1 (smooth—typical peak to trough of wave < 4")
- 2 (medium—typical peak to trough of wave < 8")
- 3 (rough—typical peak to trough of wave > 8")

The factory default water conditions are set to 1, which is smooth. The water condition settings should closely mimic the actual water conditions during normal river flow.

Change this setting by first using the **aXSWC+n!** command (where n=0 (custom), 1 (smooth), 2 (medium), or 3 (rough)) followed by the **aXGWC!** (*Get Water*

*Conditions*) command. Table B-5 shows an example of the command and response for changing this setting.

**Table B-5. Example for Setting Water Conditions**

| **Initial Command** | **Response** |
|---|---|
| **0XSWC+2!**<br>Where,<br>0—sensor's address;<br>2—the new water condition setting (2 = medium). | **00011<cr><lf>**<br>Where (from left to right),<br>0—sensor's address;<br>001—the amount of time (in seconds) that you must wait before sending another command;<br>1—the number of values that will be placed in the buffer. |
| **Subsequent Command** | **Response** |
| **0XGWC!**<br>Where zero is the sensor address.<br>This is the send water conditions command. | **0+2<cr><lf>**<br>Where,<br>0—sensor's address;<br>2—the new water condition setting (2 = medium). |

## B.1.6 Set Power Operation Mode

The following three power operation modes are available:

- 1 (ON—sensor is always on until a new set power command is received.)
- 2 (AUTO—sensor is powered by an incoming request from the SDI-12 bus and sends back a response including the information on power up time.)
- 0 (OFF—this mode is typically not recommended; sensor is completely off until a new set power command is received)

**CAUTION** The OFF power mode should only be used by advanced users who want to turn the sensor off for extended time periods. In this mode, the sensor is completely off and only responds to a new set power command.

The factory default *Power Operation Mode* is 1 (ON). In this mode of operation, the instrument is continuously making measurements and draws approximately 13.5 mA. The AUTO Power Operation Mode puts the instrument in quiescent mode between measurement request queries.

Change this setting by first using the **aXSPOM+n!** command (where n=1 (on), 2 (auto), or 0 (off)) followed by the **aXGPOM!** (*Get Power Mode*) command. Table B-6 shows an example of the command and response for changing this setting.

**Table B-6. Example for Setting Power Operation Mode**

| **Initial Command** | **Response** |
|---|---|
| **0XSPOM+2!** | **00011<cr><lf>** |

| | |
|---|---|
| Where,<br>0—sensor's address;<br>2—the new power mode setting (2 = auto). | Where (from left to right),<br>0—sensor's address;<br>001—the amount of time (in seconds) that you must wait before sending another data command;<br>1—the number of values that will be placed in the buffer. |
| **Subsequent Command** | **Response** |
| **aXGPOM!**<br>Where zero is the sensor address.<br>This is the get power mode command. | **0+2<cr><lf>**<br>Where,<br>0—sensor's address;<br>2—the new power mode setting (2 = auto). |

# B.2 Using Terminal Emulator and a Datalogger to Send Commands

Commands can be sent to the sensor by connecting the sensor to an SDI-12 compatible central port on a datalogger and use the SDI-12 transparent mode.

## B.2.1 SDI-12 Transparent Mode

System operators can manually interrogate and enter settings in probes using transparent mode. Transparent mode is useful in troubleshooting SDI-12 systems because it allows direct communication with probes. Datalogger security may need to be unlocked before transparent mode can be activated.

Transparent mode is entered while the PC is in telecommunications with the datalogger through a terminal emulator program. It is easily accessed through Campbell Scientific datalogger support software, but is also accessible with terminal emulator programs such as Windows HyperTerminal. Datalogger keyboards and displays cannot be used.

The terminal emulator is accessed by navigating to the Datalogger menu in PC200W, the Tools menu in PC400, or the Datalogger menu in the Connect screen of LoggerNet.

The following examples show how to use LoggerNet software to enter transparent mode and change the SDI-12 address of a sensor. The same steps are used to enter transparent mode with PC200W and PC400 software after accessing the terminal emulator as previously described.

## B.2.2 CR200(X) Series Datalogger Example

1. Connect a single sensor to the datalogger as follows:
   - White to Control Port C1/SDI12
   - Black, Orange, Clear to G
   - Red to Battery +
2. In the LoggerNet Connect screen navigate to the Datalogger menu and select Terminal Emulator. The "Terminal Emulator" window will open. In the

Select Device menu, located in the lower left-hand side of the window, select the CR200Series station.

3. Click on the Open Terminal button.

4. Press the <enter> key until the datalogger responds with the "**CR2XX>**" prompt. At the "**CR2XX>**" prompt, make sure the All Caps Mode box is checked and enter the command **SDI12** <enter>. The response "SDI12>" indicates that the sensor is ready to accept SDI-12 commands.

5. To query the sensor for its current SDI-12 address, key in ?! <enter> and the sensor will respond with its SDI-12 address. If no characters are typed within 60 seconds, then the mode is exited. In that case, simply enter the command SDI12 again and press <enter>.




*Figure B-2. SDI-12 transparent mode on CR200(X)-series datalogger using control port C1/SDI12 and changing SDI-12 address from 0 to 1*

6. To change the SDI-12 address, key in **aAb!<enter>** where *a* is the current address from the above step and *b* is the new address. The sensor will change its address and the datalogger will respond with the new address. To exit SDI-12 transparent mode select the Close Terminal button.

## B.2.3 CR1000 Datalogger Example

1. Connect a single sensor to the datalogger as follows:

   - White to Control Port C1
   - Black, Orange, Clear to G
   - Red to 12V

2. In the LoggerNet Connect screen navigate to the Datalogger menu and select Terminal Emulator. The "Terminal Emulator" window will open. In the Select Device menu, located in the lower left-hand side of the window, select the CR1000 station.

3. Click on the Open Terminal button.

4. Press the <enter> key until the datalogger responds with the "**CR1000>**" prompt. At the "**CR1000>**" prompt, make sure the All Caps Mode box is checked and enter the command **SDI12** <enter>. At the "Enter Cx Port 1, 3,

5, or 7" prompt, key in the control port number where the sensor's white lead is connected and <enter>. The response "Entering SDI12 Terminal" indicates that the sensor is ready to accept SDI-12 commands.

5. To query the sensor for its current SDI-12 address, key in ?! <enter> and the sensor will respond with its SDI-12 address. If no characters are typed within 60 seconds, then the mode is exited. In that case, simply enter the command SDI12 again, press <enter>, and key in the correct control port number when prompted.




*Figure B-3. SDI-12 transparent mode on CR1000 datalogger using control port 1 and changing SD1-12 address from 3 to 1*

6. To change the SDI-12 address, key in **aAb!<enter>** where *a* is the current address from the above step and *b* is the new address. The sensor will change its address and the datalogger will respond with the new address. To exit SDI-12 transparent mode, press the Esc key or wait for the 60 second timeout, then select the Close Terminal button.

## B.2.4 CR10X Datalogger Example

1. Connect a single sensor to the datalogger as follows:
   - White to Control Port C1
   - Black, Orange, Clear to G
   - Red to 12V
2. Download a datalogger program that contains the SDI-12 Recorder (P105) instruction with valid entries for each parameter. Make sure that parameter 3 of the P105 instruction matches the control port number where the green wire is connected.
3. In the LoggerNet Connect screen navigate to the Datalogger menu and select Terminal Emulator. The "Terminal Emulator" window will open. In the Select Device menu, located in the lower left-hand side of the window, select the CR10X station.

4. Click on the Open Terminal button.

5. Press the <enter> key until the datalogger responds with the "*" prompt.

6. To activate the SDI-12 Transparent Mode on Control Port *p*, enter *p*X <enter>. For this example key in 1X <enter>. The datalogger will respond with "**`entering SDI-12`**". If any invalid SDI-12 command is issued, the datalogger will exit the SDI-12 Transparent Mode.

7. To query the sensor for its current SDI-12 address, enter the command ?!. The sensor will respond with the current SDI-12 address.

8. To change the SDI-12 address, enter the command *a*A*b*!; where *a* is the current address from the above step and *b* is the new address. The sensor will change its address and the datalogger will exit the SDI-12 Transparent Mode.

9. Activate the SDI-12 Transparent Mode on Control Port 1 again by entering 1X <enter>. Verify the new SDI-12 address by entering the ?! command. The sensor will respond with the new address.

10. To exit the SDI-12 Transparent Mode, enter *.




*Figure B-4. SDI-12 transparent mode on CR10X datalogger using control port 1 and changing SDI-12 address from 0 to 1*

## B.2.5 CR10X-PB Table-Based Datalogger Example

1. Connect a single sensor to the datalogger as follows:

   - White to Control Port C1
   - Black, Orange, Clear to G
   - Red to 12V

2. Download a datalogger program that contains the SDI-12 Recorder (P105) instruction with valid entries for each parameter. Make sure that parameter 3 of the P105 instruction matches the control port number where the green wire is connected.

3. In the LoggerNet Connect screen navigate to the Datalogger menu and select Terminal Emulator. The "Terminal Emulator" window will open. In the

Select Device menu, located in the lower left-hand side of the window, select the CR10XTD or CR10XPB station.

4. Click on the Open Terminal button.

5. Press the <enter> key until the datalogger responds with the ">" prompt.

6. To activate the SDI-12 Transparent Mode on Control Port *p*, enter ***8**. The TD datalogger will respond with a "." prompt. At the "." prompt enter **#**. The TD datalogger will respond with **150000**. Finally, enter *p* (Control Port *p*) and press the <enter> key. For this example, *p* = 1. The TD datalogger will respond with "**entering SDI-12**". If any invalid SDI-12 command is issued, the datalogger will exit the SDI-12 Transparent Mode.

7. To query the sensor for its current SDI-12 address, enter the command ?!. The sensor will respond with the current SDI-12 address.

8. To change the SDI-12 address, enter the command *a*A*b*!; where *a* is the current address from the above step and *b* is the new address. The sensor will change its address and the datalogger will exit the SDI-12 Transparent Mode.

9. Activate the SDI-12 Transparent Mode on Control Port 1 again by entering *8#1 <enter>. Verify the new SDI-12 address by entering the ?! command. The sensor will respond with the new address.

10. To exit the SDI-12 Transparent Mode, type in ***0**.




*Figure B-5. SDI-12 transparent mode on CR10X-PB table-based datalogger using control port 1 and changing SDI-12 address from 0 to 1*

# Appendix C. FCC/IC Equipment Authorization (USA/Canada only)

The CS475, CS476, and CS477 are FCC compliant (FCC IC # M01PULS616263). Modifications to the sensors must have express agreement from Campbell Scientific. Any modifications not approved by Campbell Scientific will cause the expiration of the operating license issued by the FCC/IC. The radar sensor is in conformity with Part 15 of the FCC directives and fulfils the RSS-210 regulations.

Regulations for operation include:

- These devices must not cause any interfering emissions.
- These devices must accept any interfering emissions received, including interference that may cause unwanted operating conditions.

## CAMPBELL SCIENTIFIC COMPANIES


**Campbell Scientific, Inc. (CSI)**
815 West 1800 North
Logan, Utah 84321
UNITED STATES
www.campbellsci.com • info@campbellsci.com

**Campbell Scientific Africa Pty. Ltd. (CSAf)**
PO Box 2450
Somerset West 7129
SOUTH AFRICA
www.csafrica.co.za • sales@csafrica.co.za

**Campbell Scientific Australia Pty. Ltd. (CSA)**
PO Box 8108
Garbutt Post Shop
QLD 4814 AUSTRALIA
www.campbellsci.com.au • info@campbellsci.com.au

**Campbell Scientific do Brazil Ltda. (CSB)**
Rua Luisa Crapsi Orsi, 15 Butantã
CEP: 005543-000 São Paulo SP BRAZIL
www.campbellsci.com.br • suporte@campbellsci.com.br

**Campbell Scientific Canada Corp. (CSC)**
11564 - 149th Street NW
Edmonton, Alberta T5M 1W7
CANADA
www.campbellsci.ca • dataloggers@campbellsci.ca

**Campbell Scientific Centro Caribe S.A. (CSCC)**
300N Cementerio, Edificio Breller
Santo Domingo, Heredia 40305
COSTA RICA
www.campbellsci.cc • info@campbellsci.cc

**Campbell Scientific Ltd. (CSL)**
Campbell Park
80 Hathern Road
Shepshed, Loughborough LE12 9GX
UNITED KINGDOM
www.campbellsci.co.uk • sales@campbellsci.co.uk

**Campbell Scientific Ltd. (France)**
3 Avenue de la Division Leclerc
92160 ANTONY
FRANCE
www.campbellsci.fr • info@campbellsci.fr

**Campbell Scientific Spain, S. L.**
Avda. Pompeu Fabra 7-9
Local 1 - 08024 BARCELONA
SPAIN
www.campbellsci.es • info@campbellsci.es

**Campbell Scientific Ltd. (Germany)**
Fahrenheitstrasse13, D-28359 Bremen
GERMANY
www.campbellsci.de • info@campbellsci.de


*Please visit www.campbellsci.com to obtain contact information for your local US or International representative.*